

Installation



The Only Bedliner That Works™

CHEVY/GMC
1999-2007 Classic body styles

1-800-992-1949



While temperature does not affect your DualLiner, it is easiest to install when bedliner is above 50 degrees Fahrenheit. If working in colder temperatures, it is helpful to warm the bedliner indoors, prior to installation. The mat may take a “set” while rolled. If possible, unroll and let it “relax” in the sun for a little while to make it easier to work with. If installing in cold weather, the mat may take several weeks to fully relax.

First step is to install loadguard panel. Snap the loadguard panel over the loadguard at the front of bed. Be sure it is in front of the forward tie downs. Tuck the sidewall under the side rail, starting at the back. If your truck has rail caps, tuck the ends of the sidewall behind the rail cap. The rear tie down should protrude through the sidewall before the rear edge of the wheel is pushed tight to the side. Continue forward, pushing the sidewall tight to truck bed. Be sure the front tie down protrudes through hole. Then, take the rear clip and snap it at the top left side. There is an existing hole in the truck where the clip will snap into. Align the holes in the front corner (use a Phillips screwdriver as an alignment tool, if needed) and press one pine-tree push pin into each hold. Repeat on opposite side.



With ribbed side up and notch for the fuel filler to the right front, lift the mat into the truck bed and tuck it into the channel in the rails. It is generally easiest to tuck one side; then fit the other side. Make sure it is pulled as far forward as possible for best fit.

Install the tailgate panel using the top two handle bolts. Align the panel and then retighten the bolts. Drill ¼” holes in the center of each slot of the panel. Lift up the panel and clear any drill chips away. Using the rust preventative gel, apply some to both the hole and the pine cone pin. Insert one pin in each hole, twisting as you press in the place to evenly distribute the gel.





Real Truck Bed Protection System

DualLiner.com
CustomerService@DualLiner.com
West Bend, WI 53095
800-992-1949

Real Lifetime Warranty

Thank you for selecting the DualLiner, The Only Bedliner That Works®! You have chosen the best way to protect your truck and cargo.

DualLiner warrants the DualLiner bedliner against defects in material and workmanship for the life of the bedliner. Warranty is transferable to new owner of truck or bedliner. Failures due to improper installation are not covered. DualLiner reserves all rights and privileges with regard to warranty determination. Please contact DualLiner at 800-992-1949 for any warranty questions.

Limited liability: The foregoing remedy of component replacement is at the manufacturer's discretion and is the buyer's sole remedy. Manufactured components are subject to variance. Both polyethylene and rubber components are effected by heat, cold, sun and other environmental factors. Due to these tolerances it is important to note that manufactured parts may shift and change depending on environmental factors for the life of the product. See Terms & Conditions for further definition.

This warranty is in lieu of any other warranty, expressed or implied. It includes replacement of the failed component. It does not include installation labor, nor does it cover any consequential damages caused by loss of use of the vehicle or failure of the component. Manufacturer's maximum liability under this agreement shall not, in any case, exceed the price of the product claimed to be defective. There are no warranties of merchantability or fitness for a particular purpose.

Please go to www.DualLiner.com for warranty registration.

CHEVY/GMC 1999 – 2007 CLASSIC BODY STYLES INSTALLATION PARTS:
(GMPAK1)

16 Pine Tree (push pins)
2 Chevy Clips
1 Rust Inhibitor Gel Pack