

Installation



CHEVY/GMC
Silverado/Sierra
2007 - 2013
1-800-992-1949

The Only Bedliner That Works™



While temperature does not affect your DualLiner, it is easiest to install when the bedliner is above 50 degrees Fahrenheit. If working in colder temperatures, it is helpful to warm the bedliner indoors prior to installation. The mat may take a “set” while rolled. If possible, unroll and let it “relax” in the sun for a little while to make it easier to work with. If installing in cold weather, the mat may take several weeks to fully relax.

First, snap the loadguard panel over the truck loadguard at front of bed. Be sure it is in front of the forward tie downs. Tuck the sidewall under the side rail, starting at the back.* If your truck has rail caps, tuck the ends of the sidewall behind the rail cap. The rear edge of the panel should be slipped behind the rail cap (if so equipped). Be sure that both tie downs protrude through sidewall holes. Align the holes in the front corners cones (use a Phillips screwdriver as an alignment tool, if needed) and press one pine-tree pin into each hole. Repeat on opposite side.



With ribbed side up, lift the mat into the truck bed and tuck it into the channel in the rails. It is generally easiest to tuck one side; then fit the other side. Make sure it is pulled as far forward as possible for best fit. The mat will “settle” into the best fit position over the first hundred miles or so of driving.

Install the tailgate panel using the top two handle bolts. Align the panel and then retighten the bolts. Drill $\frac{1}{4}$ holes in the center of each slot of the panel. Lift up the panel and clear any drill chips away. Using the rust preventive gel, apply some to both the hole and pine cone pin. Insert one pin in each hole, twisting as you press in place to evenly distribute the gel.



*If you have the factory tie down rail set, remove the rail set from the bed side at this time. Prior to installation of the DualLiner sidewall panels, you will need to open up the mounting holes, which are defined by depressions in the panel. These align with the tie down rail holes in the truck. They can be opened with any drill type tool. Use care. Do not over-cut the size of the hole. Using a Unibit or Dremel tool is the easiest tool to use. Also, having someone hold the sidewall will simplify accurate cuts. Make a starter hold and look at alignment of the hole prior to continuing to assure the best finish.



Real Truck Bed Protection System

DualLiner.com
CustomerService@DualLiner.com
West Bend, WI 53095
800-992-1949

Real Lifetime Warranty

Thank you for selecting the DualLiner, The Only Bedliner That Works®! You have chosen the best way to protect your truck and cargo.

DualLiner warrants the DualLiner bedliner against defects in material and workmanship for the life of the bedliner. Warranty is transferable to new owner of truck or bedliner. Failures due to improper installation are not covered. DualLiner reserves all rights and privileges with regard to warranty determination. Please contact DualLiner at 800-992-1949 for any warranty questions.

Limited liability: The foregoing remedy of component replacement is at the manufacturer's discretion and is the buyer's sole remedy. Manufactured components are subject to variance. Both polyethylene and rubber components are effected by heat, cold, sun and other environmental factors. Due to these tolerances it is important to note that manufactured parts may shift and change depending on environmental factors for the life of the product. See Terms & Conditions for further definition.

This warranty is in lieu of any other warranty, expressed or implied. It includes replacement of the failed component. It does not include installation labor, nor does it cover any consequential damages caused by loss of use of the vehicle or failure of the component. Manufacturer's maximum liability under this agreement shall not, in any case, exceed the price of the product claimed to be defective. There are no warranties of merchantability or fitness for a particular purpose.

Please go to www.DualLiner.com for warranty registration.

CHEVY/GMC 2007 – CURRENT, INSTALLATION PARTS:

(GMPAK02)

16 Pine-Tree (push pins)

1 Rust Inhibitor Gel Pack

4 Strips Double Sided Tape

1 Alcohol Wipe