

# Installation



**DODGE RAM**  
**2002 – CURRENT**  
**1-800-992-1949**

**The Only Bedliner That Works™**



While temperature does not affect you DualLiner, it is easiest to install when bedliner is above 50 degrees Fahrenheit. If working in colder temperatures, it is helpful to warm the bedliner indoors prior to installation. The mat may take a “set” while rolled. If possible, unroll and let it “relax” in the sun for a while to make it easier to work. If installing in cold weather, the mat may take several weeks to fully relax.

Dodge made a change to their beds in early 2007, switching from bolt in tie down to a welded in tie down. Remove four bed tie downs if applicable; otherwise, the sidewall will fit right over tie downs. Next, snap loadguard panel over the truck loadguard at front of bed. Tuck the sidewall under the side rail. If your truck has rail caps, tuck the ends of the sidewall behind the rail cap. Align the holes in the front corner (use a Phillips screwdriver as an alignment tool, if needed) and press one pine-tree pin into each hole. If you have the bolt in tie downs, use your Phillips head to align the tie down holes. Insert the tie down screws, leaving them loose until all four are started; then tighten all four. Repeat on opposite side.



With ribbed side up, lift the mat into the truck bed and tuck it into the channel in the rails. It is generally easiest to tuck one side; then fit the other side. Make sure it is pulled as far forward as possible for best fit.

Install the tailgate panel using the access latch panel screws. Note that two are not removed to simplify the installation. Align the panel. Use one nylon spacer on each bolt, and then retighten the bolts. Drill  $\frac{1}{4}$ " holes in the center of each slot of the panel. Lift up the panel and clear any drill chips away. Using the rust preventative gel, apply some to both the hole and the pine cone pin. Insert one pin in each hole, twisting as you press in place to evenly distribute the gel. We have also included a double-sided tape option, should you choose not to drill.(See Insert)



**\*\*Note:** For 2009-Newer Dodge Rams to install the tailgate, using a T30 Torx Driver, remove and save 6 screws from the truck tailgate. Place the plastic tailgate cover on the tailgate lining up the holes. Apply a nylon spacer to each bolt and fasten the tailgate cover to the tailgate. Do Not Over-Tighten, and Do Not use power tools.



**Real** Truck Bed Protection System

DualLiner.com  
CustomerService@DualLiner.com  
West Bend, WI 53095  
800-992-1949

## **Real Lifetime Warranty**

Thank you for selecting the DualLiner, The Only Bedliner That Works®! You have chosen the best way to protect your truck and cargo.

DualLiner warrants the DualLiner bedliner against defects in material and workmanship for the life of the bedliner. Warranty is transferable to new owner of truck or bedliner. Failures due to improper installation are not covered. DualLiner reserves all rights and privileges with regard to warranty determination. Please contact DualLiner at 800-992-1949 for any warranty questions.

Limited liability: The foregoing remedy of component replacement is at the manufacturer's discretion and is the buyer's sole remedy. Manufactured components are subject to variance. Both polyethylene and rubber components are effected by heat, cold, sun and other environmental factors. Due to these tolerances it is important to note that manufactured parts may shift and change depending on environmental factors for the life of the product. See Terms & Conditions for further definition.

This warranty is in lieu of any other warranty, expressed or implied. It includes replacement of the failed component. It does not include installation labor, nor does it cover any consequential damages caused by loss of use of the vehicle or failure of the component. Manufacturer's maximum liability under this agreement shall not, in any case, exceed the price of the product claimed to be defective. There are no warranties of merchantability or fitness for a particular purpose.

Please go to [www.DualLiner.com](http://www.DualLiner.com) for warranty registration.

---

### **DODGE RAM 2002 – CURRENT, INSTALLATION PARTS:**

(DOFPAK01)

16 Pine-Tree (push pins)

8 Nylon Spacers

1 Rust Inhibitor

4 Strips Double Sided Tape

1 Alcohol Wipe