

Installation Instructions



**Dodge Ram
2019-2020
DOF19PAK**

*Requires T30 Torx bit
NOT INCLUDED

Please read all instructions before beginning the installation process.

While temperature does not affect your DualLiner, it is easier to install when the bedliner is above 50 degrees Fahrenheit. If working in colder temperatures, it is helpful to warm the bedliner indoors prior to installation. The mat may take a "set" while rolled. If possible, unroll the mat and let it "relax" in the sun to make it easier to work with. If installing in cold weather it may take several weeks for the mat to fully relax.

Step 1: Install the loadguard panel. (Fig. 1)

- o Position the lower half of the Load Guard Panel in front of the factory tie downs.
- o Place the Load Guard panel over the front rail and snap in place.

Step 2: Install the sidewall panels. (Fig. 2)

- o Starting at a 45 degree angle, position the sidewall panel under the rail of the truck and slide in place.
- o Once in position under the rail, with tie-downs showing through the pre-trimmed holes, tuck the top edge of the sidewall panel under the factory rail cap at the tailgate end and at the front by the cab.
- o Under the Factory Rails there are push pins, make sure the sidewall is not hung up on those.
- o Repeat on opposite side.

**Important Notes: If your truck is equipped with LED lights, there are pre-cut holes for both lights.*

**To Install the Factory Utility Rail System, there are 8 Raised Circles along each sidewall for the Factory bolts. These spots will need to be drilled open to 3/8" - 1/2" before placing in the truck. (See Fig. 3)*

Step 3: Install the ZeroSkid Rubber Floor®. (Fig. 4)

- o Lift the mat into the truck and unroll with nub sidedown.
- o Start tucking the mat into the channel from front to back.

**Tip: It is generally easiest to tuck one side, then the other side.*

- o Make sure it is pulled as far forward as possible for best fit.
- o The mat will "settle" into position, sometimes giving it a kick or shuffling your feet will help it find its place.



Fig. 3

Step 4: Install the tailgate panel. (Fig. 5)

- o With T30 Torx, remove the 6 screws corresponding to the 6 pre-drilled holes on the tailgate panel, and save 6 existing factory installed screws from the top half of the tailgate using a Torx Driver.
- o Align the panel using the bolt holes as a guide.
- o Replace the factory screws to attach the tailgate panel. Finger tight-ening at first, then using a hand tool to tighten fully. Be careful not to strip the screws.

**Optional: Since the tailgate panel only attaches with hardware across the top half, we have provided double sided tape should you want to secure the bottom half. Also included is Rust Preventative Gel should you choose to drill any holes, we suggest using the gel to protect your truck.*

**Note: You will have 2 screws that are left in the tailgate and unused in the installation of the tailgate panel.*

That's it! Now your truck and your cargo are protected for a LifeTime!

Don't forget to visit DualLiner.com to register your Real LifeTime Warranty!



Fig. 1



Fig. 2



Fig. 4



Fig. 5

Have Questions? Contact Customer Service:

Phone: 800-992-1949, Email: CustomerService@DualLiner.com,

or Chat with us at DualLiner.com



Real Truck Bed Protection System®

DualLiner, LLC
143 S. Main St, 2nd Floor
West Bend, WI 53095
800-992-1949 Tel.
CustomerService@DualLiner.com

Real Lifetime Warranty

Thank you for selecting DualLiner, The Only Bedliner That Works®! You have chosen the best way to protect your truck and cargo.

DualLiner warrants the performance of the bedliner components for their life. The LifeTime Warranty must be registered with DualLiner, LLC within 30 days of purchase. Original owners can also provide Proof of Purchase under same ownership for Warranty verification. The bedliner is transferable to a new truck or owner, transfers of warranty must be re-registered through DualLiner within 5 business days of transfer. Failures due to improper installation, uninstall or reinstall are not covered. DualLiner reserves all rights and privileges with regard to warranty determination. Please contact DualLiner at 800-992-1949 for any warranty questions.

Limited liability:

The foregoing remedy of component replacement is at the manufacturer's discretion and is the buyer's sole remedy. Manufactured components are subject to variance. Both polyethylene and rubber components are affected by heat, cold, sun and other environmental factors. Due to these tolerances it is important to note that manufactured parts may shift and change depending on environmental factors for the life of the product. See Terms & Conditions for further definition.

This warranty is in lieu of any other warranty, expressed or implied. It includes replacement of the failed component. It does not include installation labor, nor does it cover any consequential damages caused by loss of use of the vehicle or failure of the component. Manufacturer's maximum liability under this agreement shall not, in any case, exceed the price of the product claimed to be defective. There are no warranties of merchantability or fitness for a particular purpose.

Please go to www.DualLiner.com for warranty registration.

*DualLiner Real Life Time Warranty, Revised June 2017
Supersedes prior Warranty Document*

INSTALLATION PARTS LIST

DODGE RAM 2019-2020:

(DOF19PAK)

1 Rust Preventative Gel Pack

4 Strips Double Sided Tape (please see insert for usage)

1 Alcohol Wipe