

# Installation Instructions



Real Truck Bed Protection System®

**DODGE RAM  
2009-2023  
"Classic"  
DOFPAK2**

\*Requires Torx T30 bit  
NOT INCLUDED

Please read all instructions before beginning the installation process.  
Install videos available at [DualLiner.com/dualliner-videos](http://DualLiner.com/dualliner-videos)

While temperature does not affect your DualLiner, it is easier to install when the bedliner is above 50 degrees Fahrenheit. If working in colder temperatures, it is helpful to warm the bedliner indoors prior to installation. The mat may take a "set" while rolled. If possible, unroll the mat and let it "relax" in the sun to make it easier to work with. If installing in cold weather it may take several weeks for the mat to fully relax.

## Step 1: Install the loadguard panel. (Fig. 1)

- Position the lower half of the Load Guard Panel in front of the factory tie downs.
- Place the Load Guard panel over the front rail and snap in place.

## Step 2: Install the sidewall panels. (Fig. 2)

- Starting at a 45 degree angle, position the side wall panel under the rail of the truck and slide in place.
- Once in position under the rail, with tie-downs showing through the pre-trimmed holes, tuck the top edge of the sidewall panel under the factory rail cap at the tailgate end and at the front.
- Behind the cab, the sidewall and load guard panels nest together and can be secured. Align the holes using a Phillips screwdriver as an alignment tool if needed and press a provided pine-tree pin into each hole. (not needed for trucks that have a rail cover)
- Repeat on opposite side.

*\*Note: The nested feature from load guard to sidewall is not required for securing the panels as the rail cap and rubber floor will interlock the system. Under the factory rails, are push pins, make sure the side walls are not hung up on these, this will not allow proper install.*

*\* If your truck is equipped with LED lights, there are pre-cut holes for both lights.*

## Step 3: Install the ZeroSkid Rubber Floor®. (Fig. 3)

- Lift the mat into the truck and unroll with nub side down.
- Start tucking the mat into the channel from front to back.

*\*Tip: It is generally easiest to tuck one side, then the other side.*

- Make sure it is pulled as far forward as possible for best fit.
- The mat will "settle" into position, sometimes giving it a kick or shuffling your feet will help it find its place.

## Step 4: Install the tailgate panel. (Fig. 4)

- Remove and save 8 existing factory installed screws from the top half of the tailgate using a T30 Torx Driver.
- Align the panel using the bolt holes as a guide.
- With a provided Nylon Spacer, replace the factory screws to attach the tailgate panel. Finger tightening at first, then using a hand tool tighten fully. Be careful not to strip the screws.

*\*Optional: Since the tailgate panel only attaches with hardware across the top half, we have provided double sided tape should you want to secure the bottom half.*

That's it! Now your truck and your cargo are protected for a LifeTime!  
Don't forget to visit [DualLiner.com](http://DualLiner.com) to register your Real LifeTime Warranty!



Fig. 1



Fig. 2



Fig. 3



Fig. 4

Have Questions? Contact Customer Service:  
Phone: 800-992-1949, Email: [CustomerService@DualLiner.com](mailto:CustomerService@DualLiner.com),  
or Chat with us at [DualLiner.com](http://DualLiner.com)



**Real** Truck Bed Protection System®

DualLiner, LLC  
143 S. Main St, 2nd Floor  
West Bend, WI 53095  
800-992-1949 Tel.  
CustomerService@DualLiner.com

## **Real Lifetime Warranty**

Thank you for selecting DualLiner, The Only Bedliner That Works®! You have chosen the best way to protect your truck and cargo.

DualLiner warrants the performance of the bedliner components for their life. The Life Time Warranty must be registered with DualLiner, LLC within 30 days of purchase. Original owners can also provide Proof of Purchase under same ownership for Warranty verification. The bedliner is transferable to a new truck or owner, transfers of warranty must be re-registered through DualLiner within 5 business days of transfer. Failures due to improper installation, uninstall or reinstall are not covered. DualLiner reserves all rights and privileges with regard to warranty determination. Please contact DualLiner at 800-992-1949 for any warranty questions.

Limited liability:

The foregoing remedy of component replacement is at the manufacturer's discretion and is the buyer's sole remedy. Manufactured components are subject to variance. Both polyethylene and rubber components are affected by heat, cold, sun and other environmental factors. Due to these tolerances it is important to note that manufactured parts may shift and change depending on environmental factors for the life of the product. See Terms & Conditions for further definition.

This warranty is in lieu of any other warranty, expressed or implied. It includes replacement of the failed component. It does not include installation labor, nor does it cover any consequential damages caused by loss of use of the vehicle or failure of the component. Manufacturer's maximum liability under this agreement shall not, in any case, exceed the price of the product claimed to be defective. There are no warranties of merchantability or fitness for a particular purpose.

Please go to [www.DualLiner.com](http://www.DualLiner.com) for warranty registration.

*DualLiner Real Life Time Warranty, Revised June 2017  
Supersedes prior Warranty Document*

### **INSTALLATION PARTS LIST**

DODGE RAM 2009–2023

“Classic”

(DOFPAK2)

16 Pine-Tree (push pins)

8 Nylon Spacers

4 Strips Double Sided Tape

1 Alcohol Wipe