

Installation



**CHEVY/GMC
Silverado/Sierra
2014-2015
1-800-992-1949**

The Only Bedliner That Works™



While temperature does not affect your DualLiner, it is easiest to install when the bedliner is above 50 degrees Fahrenheit. If working in colder temperatures, it is helpful to warm the bedliner indoors prior to installation. The mat may take a “set” while rolled. If possible, unroll and let it “relax” in the sun for a little while to make it easier to work with. If installing in cold weather, the mat may take several weeks to fully relax.

First, snap the loadguard panel over the truck loadguard at front of bed. Be sure it is in front of the forward tie downs. Tuck the sidewall under the side rail, with the ends of the sidewall under the rail cap. Be sure that tie downs protrude through sidewall holes. *If your model has upper tie downs, remove and reinstall over the side panel. Align the holes in the front corners cones (use a Phillips screwdriver as an alignment tool, if needed) and press one pine-tree pin into each hole. Repeat on opposite side.



With ribbed side up, lift the mat into the truck bed and tuck it into the channel in the rails. It is generally easiest to tuck one side; then fit the other side. Make sure it is pulled as far forward as possible for best fit. The mat will “settle” into the best fit position over the first hundred miles or so of driving.



Using a T15 Torx Driver remove the 8 existing factory installed screws from the tailgate latch plate and discard. Center plastic tailgate cover on truck tailgate. Using the rust preventive gel, apply some to both the hole and tailgate fastener. Insert and tighten tailgate fastener screws with shoulder washers provided in hardware kit in the holes of the tailgate. Using a center punch carefully mark the screw location in the center of the precut slot. Position self-drilling screw at the marked location. Fasten the screw to the tailgate with a power screwdriver. **DO NOT OVER TIGHTEN BECAUSE THE SCREW THREADS CAN BE STRIPPED EASILY.** You will repeat this step in the remaining slot location.





Real Truck Bed Protection System

DualLiner.com
CustomerService@DualLiner.com
West Bend, WI 53095
800-992-1949

Real Lifetime Warranty

Thank you for selecting the DualLiner, The Only Bedliner That Works®! You have chosen the best way to protect your truck and cargo.

DualLiner warrants the DualLiner bedliner against defects in material and workmanship for the life of the bedliner. Warranty is transferable to new owner of truck or bedliner. Failures due to improper installation are not covered. DualLiner reserves all rights and privileges with regard to warranty determination. Please contact DualLiner at 800-992-1949 for any warranty questions.

Limited liability: The foregoing remedy of component replacement is at the manufacturer's discretion and is the buyer's sole remedy. Manufactured components are subject to variance. Both polyethylene and rubber components are effected by heat, cold, sun and other environmental factors. Due to these tolerances it is important to note that manufactured parts may shift and change depending on environmental factors for the life of the product. See Terms & Conditions for further definition.

This warranty is in lieu of any other warranty, expressed or implied. It includes replacement of the failed component. It does not include installation labor, nor does it cover any consequential damages caused by loss of use of the vehicle or failure of the component. Manufacturer's maximum liability under this agreement shall not, in any case, exceed the price of the product claimed to be defective. There are no warranties of merchantability or fitness for a particular purpose.

Please go to www.DualLiner.com for warranty registration.

CHEVY/GMC 2014, INSTALLATION PARTS:

(GMPAK03)

8 Tailgate Screws

8 Shoulder Washers

2 Self Tapping Screws

12 Pine-Tree (push pins)

1 Rust Inhibitor Gel Pack

4 Strips Double Sided Tape

1 Alcohol Wipe