

Installation Instructions



Real Truck Bed Protection System®

**CHEVY Silverado/GMC Sierra
1999-2007 Classic Body Style
GMPAK1**

*Requires a 13mm wrench and a ¼" drill bit
NOT INCLUDED

Please read all instructions before beginning the installation process.
Install videos available at DualLiner.com/dualliner-videos

While temperature does not affect your DualLiner, it is easier to install when the bedliner is above 50 degrees Fahrenheit. If working in colder temperatures, it is helpful to warm the bedliner indoors prior to installation. The mat may take a "set" while rolled. If possible, unroll the mat and let it "relax" in the sun to make it easier to work with. If installing in cold weather it may take several weeks for the mat to fully relax.

Step 1: Install the loadguard panel. (Fig. 1)

- Position the bottom of the panel behind the forward tie downs.
- Place over the front rail and snap in place.

Note: We have provided double sided tape, should you need extra security.

Step 2: Install the sidewall panels. (Fig. 2)

- Tuck the sidewall panel under the side starting at the back.
- Tuck the ends of the sidewall under the rail cap (if applicable).
- Make sure the rear tie down protrudes through the panel before the rear edge of the wheel is pushed tight to the side.
- Continue forward pushing the side wall tight to the truck bed.
- Take the rear clip and snap into place on the top of the side panel near the tailgate end.

**Tip: There is an existing hole in the truck where the clip will snap into place. If you install it upside down, it is easier to remove should you want to put a tie down strap in.*

- Align the holes in the front corner's cones using a Phillips screwdriver as an alignment tool if needed and press one pine tree pin into each hole.
- Repeat on opposite side.

Note: If you have rail caps the nesting feature is not required.

Step 3: Install the ZeroSkid Rubber Floor®. (Fig. 3)

- Lift the mat into the truck and unroll with nub side down.
- Start tucking the mat into the channel from front to back.
- **Tip: It is generally easiest to tuck one side, then the other side.*
- Make sure it is pulled as far forward as possible for best fit.
- The mat will "settle" into position, giving it a kick or shuffling your feet will help it find its place.

Step 4: Install the tailgate panel. (Fig. 4)

- Remove the center two latch bolts using the 13mm wrench.
- Align the panel using the bolt holes as a guide.
- Replace the bolts.

**Optional: Drill ¼" holes in the center of each slot of the panel. Lift up the panel and clear any drill chips away. Apply some of the rust preventative gel to both the holes and the pine tree pins. Insert one pin in each hole, twisting as you press in place to evenly distribute the gel. Do not over-tighten, and do not use power tools. We have also included double-sided tape, should you choose not to drill. (See insert)*



Fig. 1



Fig. 2



Fig. 3



Fig. 4

That's it! Now your truck and your cargo are protected for a LifeTime!
Don't forget to visit DualLiner.com to register your Real LifeTime Warranty!

Have Questions? Contact Customer Service:
Phone: 800-992-1949, Email: CustomerService@DualLiner.com,
or Chat with us at DualLiner.com



Real Truck Bed Protection System®

DualLiner, LLC
143 S. Main St, 2nd Floor
West Bend, WI 53095
800-992-1949 Tel.
CustomerService@DualLiner.com

Real Lifetime Warranty

Thank you for selecting DualLiner, The Only Bedliner That Works®! You have chosen the best way to protect your truck and cargo.

DualLiner warrants the performance of the bedliner components for their life. The LifeTime Warranty must be registered with DualLiner, LLC within 30 days of purchase. Original owners can also provide Proof of Purchase under same ownership for Warranty verification. The bedliner is transferable to a new truck or owner, transfers of warranty must be re-registered through DualLiner within 5 business days of transfer. Failures due to improper installation, uninstall or reinstall are not covered. DualLiner reserves all rights and privileges with regard to warranty determination. Please contact DualLiner at 800-992-1949 for any warranty questions.

Limited liability:

The foregoing remedy of component replacement is at the manufacturer's discretion and is the buyer's sole remedy. Manufactured components are subject to variance. Both polyethylene and rubber components are affected by heat, cold, sun and other environmental factors. Due to these tolerances it is important to note that manufactured parts may shift and change depending on environmental factors for the life of the product. See Terms & Conditions for further definition.

This warranty is in lieu of any other warranty, expressed or implied. It includes replacement of the failed component. It does not include installation labor, nor does it cover any consequential damages caused by loss of use of the vehicle or failure of the component. Manufacturer's maximum liability under this agreement shall not, in any case, exceed the price of the product claimed to be defective. There are no warranties of merchantability or fitness for a particular purpose.

Please go to www.DualLiner.com for warranty registration.

*DualLiner Real LifeTime Warranty, Revised June 2017
Supersedes prior Warranty Document*

INSTALLATION PARTS LIST

CHEVY SILVERADO/GMC SIERRA 1999-2007 CLASSIC BODY STYLE:

(GMPAK1)

16 Pine Tree (push pins)

2 Chevy Clips

1 Rust Inhibitor Gel Pack

4 Strips, Double Sided Tape

1 Alcohol Wipe